

ATTACCHI SPECIFICI PER - SPECIFIC FITTING KIT FOR  
 KIT DE MONTAGE SPECIFIQUE POUR - SPEZIFISCHER MONTAGEKIT FÜR  
 ANCLAJE ESPECIFICO PARA

# SUZUKI BANDIT 650-1250

2007

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS  
 INSTRUCTIONS DE MONTAGE - BAUANLEITUNG - INSTRUCCIONES DE MONTAJE


1



**SUPPORTO**  
 SUPPORT  
 SUPPORT  
 HALTERUNG  
 SOPORTE

**Q.TY n.2(Dx-Sx)**

2



**Q.TY n.-**

3



**DISTANZIALE Ø8x10mm**  
**Foro Ø6,5mm, V269**  
 SPACER  
 ENTRETÔISE  
 DISTANZSTÜCK  
 DISTANCIADOR

**Q.TY n.4**


4



**DISTANZIALE Ø20x3mm**  
**foro Ø6,5mm V244**  
 SPACER  
 ENTRETÔISE  
 DISTANZSTÜCK  
 DISTANCIADOR

**Q.TY n. 4**

5



**RONDELLA Ø6mm**  
**INOX**  
 WASHER Ø6mm  
 RONDELLE Ø6mm  
 SCHEIBE Ø6mm

**Q.TY n.8**


6



**VITE TBEI M6x25mm**  
 SCREW M6x25mm  
 VIS M6x25mm  
 SCHRAUBE M6x25mm  
 TORNILLO M6x25mm

**Q.TY n.4**


7



**RONDELLA IN GOMMA**  
**ORONG**  
 RUBBER WASHER  
 RONDELLE EN CAOUTCHOUC  
 GUMMI SCHEIBE  
 ARANDELA DE GOMA

**Q.TY n.4**


8



**RONDELLA SVASATA Ø6mm**  
**200RON**  
 WASHER Ø6mm  
 RONDELLE Ø6mm  
 SCHEIBE Ø6mm  
 ARANDELA VACIADA Ø6mm

**Q.TY n.4**


9



**GOMMA SAGOMATA**  
**OGUARN**  
 RUBBER CUSHION  
 CAOUTCHOUC PROFILÉ  
 GEFORMTE GUMMI  
 GOMA PROTECTORA

**Q.TY n.2**


10



**VITE TSCEI M6x18mm**  
**INOX**  
 SCREW M6x30mm  
 VIS M6x30mm  
 SCHRAUBE M6x30mm  
 TORNILLO M6x30mm

**Q.TY n.4**

11



**DADO CIECO M6**  
 BOLT M6  
 ECROU M6  
 MUTTER M6  
 TUERCA CIEGA M6

**Q.TY n.4**

